


## **Installing the XG-470 gas fuel tank**

The Tank on the XG470 doesn't come installed from the factory so it is necessary for the customer to install it.


### **To install the Tank:**

1. Using an adjustable wrench or allen wrench, turn the screw counter-clockwise to loosen. (Fig.1)



2. Using a adjustable wrench or allen wrench, turn the screw clockwise to tighten the Tank.(Fig.2)

3. Let the fuel lines go behind the seat pole, make sure the two fuel lines connect the engine correctly. (Fig.3)



4. The fuel system consists of the carburetor (1) fuel tank (2) fuel supply line (3) fuel return line (4) fuel filter and tank vent (5).

If you need technical assistance installing the tank, please visit our technical support team at [www.x-tremescooters.com/support/](http://www.x-tremescooters.com/support/) & open a support ticket.